



# Driver's Guide

## D4505



1. Main Battery Disconnect Switch
2. Exterior Entrance Door and Kneel Switch
3. Entrance Door Air Dump Valve Switch
4. Baggage Door Lock
5. Wheelchair Lift
6. Lift Control Pendant Switch
7. Horn/Foot Operated on Driver Footrest
8. Park Brake Valve on Lower, RH Console
9. Entertainment Controller and AM/FM CD Player

### MCI Sales and Service Centers

10 East Golf Road  
Des Plaines, IL 60016 USA  
(866) 624-2622

14 Harmon Drive  
Blackwood, NJ 08012 USA  
(800) 262-1287

1400 Barre Street  
Montreal, QC H3C 1N4 Canada  
(800) 663-3328

3718 LB McLeod Road  
Orlando, FL 32805 USA  
(800) 390-0287

9787 Clifford Drive  
Dallas, TX 75220 USA  
(800) 248-4942

10850 Portal Drive  
Los Alamitos, CA 90720 USA  
(800) 777-4101

1501 Albany Boulevard  
Atlantic City, NJ 08401  
(800) 263-1041

215 Maddox Simpson Parkway,  
Lebanon, TN 37090  
(800) 927-5041

**MCI Major Repair Center**  
520 North Spring Street  
Loudonville, OH 44842  
(877) 754-4404

**Parts**  
To order parts:  
(800) 323-1238 (US)  
(800) 665-0155 (Canada/ English)  
(800) 546-3457 (Canada/Francais)

**Technical Support and  
Emergency Roadside Assistance**  
(800) 241-2947



MOTOR COACH  
INDUSTRIES

*Going further!*

[www.mcicoach.com](http://www.mcicoach.com)



MOTOR COACH  
INDUSTRIES

Prior to unit number **57337**



#### Lower, LH Console

1. Mirror Control
2. Auxiliary Power
3. Rear Lift Switch
4. Kneeling Switch
5. Entrance Door Open/Close Switch
6. SmarTire Display (Optional)
7. Transmission Retarder Joystick (Optional)
8. Automatic Transmission Pushbutton Shift Selector
9. Cup Holder
10. Parcel Rack Ventilation Switch
11. Mirror Heat Switch
12. Steering Axle Switch
13. Auxiliary Heat Switch

Prior to unit number 57337.

Vehicle specifications may change without notice.

#### Dashboard Controls

1. Stepwell Light Switch
2. Hazard/Warning Light Switch
3. Test/Reading Light Switch
4. Drivers Light Switch
5. Clearance/ID Light Switch
6. Headlamps
7. Panel Illumination
8. Interior Light Switch
9. Driving Light Switch
10. Front Entrance Light Switch
11. Engine Start Switch
12. Master Power Ignition Switch
13. Engine Override Switch
14. Engine Brake Switch
15. Fast Idle Switch
16. Cruise Control Enable Switch
17. Set/Coast Resume/Accel Switch
18. Drivers Fan (Defrost)
19. Heating and A/C Control Panel
20. Turn Signal/Air Horn
21. Steering Column Adjustment
22. Entrance Door Air Dump Valve
23. Windshield Wipers and Washers
24. P.A. System
25. Baggage Door Locks
26. Vent
27. Instrument Panel
28. Coolant Temperature Gauge
29. Oil Pressure Gauge
30. Voltmeter Gauge
31. Fuel Gauge
32. Front Air Pressure Gauge
33. Rear Air Pressure Gauge
34. Speedometer
35. Tell tales
36. Wheelchair Lift Master Switch (Optional/Not shown)
37. Horn

