




# Driver's Guide

## D4505



- 1. Main Battery Disconnect Switch
- 2. Exterior Entrance Door and Kneel Switch
- 3. Entrance Door Air Dump Valve Switch
- 4. Baggage Door Lock
- 5. Wheelchair Lift
- 6. Lift Control Pendant Switch
- 7. Horn/Foot Operated on Driver Footrest
- 8. Park Brake Valve on Lower, RH Console
- 9. Entertainment Controller and AM/FM CD Player

### MCI Sales and Service Centers

10 East Golf Road  
Des Plaines, IL 60016 USA  
(866) 624-2622

14 Harmon Drive  
Blackwood, NJ 08012 USA  
(800) 262-1287

1400 Barre Street  
Montreal, QC H3C 1N4 Canada  
(800) 663-3328

3718 LB McLeod Road  
Orlando, FL 32805 USA  
(800) 390-0287

9787 Clifford Drive  
Dallas, TX 75220 USA  
(800) 248-4942

10850 Portal Drive  
Los Alamitos, CA 90720 USA  
(800) 777-4101

1501 Albany Boulevard  
Atlantic City, NJ 08401  
(800) 263-1041

215 Maddox Simpson Parkway,  
Lebanon, TN 37090  
(800) 927-5041

**MCI Major Repair Center**  
520 North Spring Street  
Loudonville, OH 44842  
(877) 754-4404

**Parts**  
To order parts:  
(800) 323-1238 (US)  
(800) 665-0155 (Canada/ English)  
(800) 546-3457 (Canada/Francais)

**Technical Support and  
Emergency Roadside Assistance**  
(800) 241-2947



MOTOR COACH  
INDUSTRIES

*Going further!*



MOTOR COACH  
INDUSTRIES

Effective with unit number **57337**



#### Lower, LH Console

1. Mirror Control
2. Auxiliary Power
3. Rear Lift Switch
4. Driving Light Switch
5. SmarTire Display (Optional)
6. Transmission Retarder Joystick (Optional)
7. Automatic Transmission Pushbutton Shift Selector
8. Cup Holder
9. Parcel Rack Ventilation Switch
10. Mirror Heat Switch
11. Steering Axle Switch
12. Auxiliary Heat Switch

Effective with unit number 57337.

Vehicle specifications may change without notice.

#### Dashboard Controls

1. Stepwell Light Switch
2. Kneeling Switch
3. Entrance Door Open/Close Switch
4. Test/Reading Light Switch
5. Panel Illumination
6. Drivers Light Switch
7. Clearance/ID Light Switch.
8. Headlamps
9. Hazard/Warning Light Switch
10. Interior Light Switch
11. Front Entrance Light Switch
12. Engine Start Switch
13. Master Power Ignition Switch
14. Engine Override Switch
15. Engine Brake Switch
16. Fast Idle Switch
17. Cruise Control Enable Switch
18. Set/Coast Resume/Accel Switch
19. Drivers Fan (Defrost)
20. Heating and A/C Control Panel
21. Turn Signal/Air Horn
22. Steering Column Adjustment
23. Entrance Door Air Dump Valve
24. Windshield Wipers and Washers
25. P.A. System
26. Baggage Door Locks
27. Vent
28. Instrument Panel
29. Coolant Temperature Gauge
30. Oil Pressure Gauge
31. Voltmeter Gauge
32. Fuel Gauge
33. Front Air Pressure Gauge
34. Rear Air Pressure Gauge
35. Speedometer
36. Tell tales
37. Wheelchair Lift Master Switch (Optional/Not shown)
38. Horn

