

Driver's Guide

J4500



MCI Sales and Service Centers

10 East Golf Road
Des Plaines, IL 60016 USA
(866) 624-2622

14 Harmon Drive
Blackwood, NJ 08012 USA
(800) 262-1287

1400 Barre Street
Montreal, QC H3C 1N4 Canada
(800) 663-3328

3718 LB McLeod Road
Orlando, FL 32805 USA
(800) 390-0287

9787 Clifford Drive
Dallas, TX 75220 USA
(800) 248-4942

10850 Portal Drive
Los Alamitos, CA 90720 USA
(800) 777-4101


1501 Albany Boulevard
Atlantic City, NJ 08401
(800) 263-1041

215 Maddox Simpson Parkway,
Lebanon, TN 37090
(800) 927-5041

MCI Major Repair Center
520 North Spring Street
Loudonville, OH 44842
(877) 754-4404

Parts
To order parts:
(800) 323-1238 (US)
(800) 665-0155 (Canada/ English)
(800) 546-3457 (Canada/Francais)

**Technical Support and
Emergency Roadside Assistance**
(800) 241-2947



1. Main Battery Disconnect Switch
2. Exterior Entrance Door Switch
3. Entrance Door Air Dump Valve Switch
4. Wheelchair Lift
5. Wheelchair Lift Hand Held Controller
6. Cruise Control—ON Switch
7. Cruise Control—OFF Switch
8. Cruise Control—SET Switch
9. Cruise Control—RESUME Switch
10. Cruise Control—CANCEL Switch
11. Jake Brake Control—OFF
12. Jake Brake Control—LOW
13. Jake Brake Control—MEDIUM
14. Jake Brake Control—HIGH




MOTOR COACH
INDUSTRIES

*Going further!*SM



MOTOR COACH
INDUSTRIES



- 1. Wheelchair Lift Master Switch (Optional/Not shown)
- 2. Cup holder
- 3. SmarTire Display
- 4. Power Blind Switches (Optional)
- 5. Front Service Compartment Door Release
- 6. 12 Volt Power Source
- 7. 12 Volt Binding Post
- 8. Emergency Park Brake Release Valve
- 9. Mirror Heat Switch
- 10. Mirror Controls
- 11. Transmission Control

Dashboard Controls

- 1. LH Baggage Lock Switch
- 2. RH Baggage Lock Switch
- 3. Reading Lights Switch
- 4. Rear Rise Switch
- 5. Kneeling Switch
- 6. Entrance Door Open/Close Switch
- 7. Baggage Bay Lights Switch
- 8. Driver's Light Switch
- 9. Dash Glow/Dimmer
- 10. Road Lights Switch
- 11. Aisle Lights Switch
- 12. Stepwell Lights Switch
- 13. Hazard/Warning Lights Switch
- 14. Tag Axle Unload Switch
- 15. Mud/Snow Switch
- 16. ABS Code Switch
- 17. Fast Idle Switch
- 18. Engine Override Switch
- 19. Master Power Ignition Switch
- 20. Engine Start Switch
- 21. Parcel Rack Ventilation Switch
- 22. Auxiliary Heater Switch
- 23. Driver's Fan (Defrost)
- 24. Drivers Heat Control
- 25. Micromate Control Panel
- 26. Turn Signal / Air Horn / High Beam / Windshield Washer and Wipers Controller
- 27. Steering Column Adjustment
- 28. Park Brake Valve
- 29. Entrance Door Air Dump Valve
- 30. Vent
- 31. Instrument Panel
- 32. Transmission Touch Pad Module
- 33. Voltmeter Gauge
- 34. Oil Pressure Gauge
- 35. Water Pressure Gauge
- 36. Engine Tachometer
- 37. Speedometer
- 38. Front Air Pressure Gauge
- 39. Rear Air Pressure Gauge
- 40. Fuel Gauge
- 41. Tell tales
- 42. CD Player/Receiver



Vehicle Specifications may change without notice.